





DO NOT OPEN  
PACKAGE WITH  
A KNIFE


## YOU SHOULD HAVE




BRACKETS




SAFETY DEVICE



HOLD-DOWN BRACKET (x2)




VALANCE & RETURN CLIPS



## SCREWS REQUIRED

Please use the correct screw  
types for your wall/surface



## TOOLS REQUIRED

- Screwdriver
- Pencil
- Power-Drill
- Tape Measure

THE INSTALLATION HEIGHT OF THIS BLIND MUST NOT BE LESS THAN 1500MM  
FROM THE FLOOR IF A CORD OR CHAIN IS USED TO OPERATE.

## FITTING THE BOX BRACKETS


### OUTSIDE RECESS

If the blind is to be fitted outside  
the window ensure that measure-  
ment C is the same. Follow instruc-  
tions for FACE FIXING. To calculate  
 $C = (A - B) / 2$ .

### INSIDE RECESS


TOP FIX to the lintel or FACE FIX  
brackets to the window frame.

← (A) Width of Blind →




### TOP FIXING

Measure & mark the distance  
between the wall & the back of the  
bracket, allowing for obstructions  
like handles that protrude into the  
recess area. The brackets should  
be positioned 6mm wider than  
the blind at each end. Hold each  
bracket into place and mark the  
hole positions. Fit each bracket  
using the screws provided. Please  
ensure fixings are suitable for the  
wall/surface to which you are  
mounting the brackets.




### FACE FIXING

The brackets should be positioned  
6mm wider than the blind at each end.  
Hold each bracket into place and mark  
the hole positions. Fit each bracket  
using the screws provided. Please  
ensure fixings are suitable for the wall/  
surface to which you are mounting the  
brackets.




### SIDE FIXING

Hold each bracket into place and mark  
the hole positions. Fit each bracket  
using the screws provided. Please  
ensure fixings are suitable for the wall/  
surface to which you are mounting the  
brackets.



### CENTRE SUPPORT BRACKET

For larger width blinds a centre  
support bracket is required.  
Align the top of the centre support  
bracket with the top of the mounting  
bracket before installation.  
Install with the bigger flap of the  
centre support bracket on the top  
equally spaced along the width of the  
headrail and clear of the slat  
ladder positions.




CHILDREN CAN STRANGLE IF A  
SAFETY DEVICE IS NOT INSTALLED.  
ALWAYS USE A SAFETY DEVICE TO  
KEEP CORDS AND CHAINS OUT OF  
REACH OF CHILDREN.


## FITTING THE HEADRAIL

### VALANCE CLIP

Hook the valance clips evenly along the length of the headrail, prior to installing the blind in the brackets.




Open the gate of the box brackets and slide the headrail into position then snap the brackets closed.



| Number of ladders | End fix brackets | Centre support brackets (supplied) |
|-------------------|------------------|------------------------------------|
| 2                 | 2                | 0                                  |
| 3                 | 2                | 1                                  |
| 4                 | 2                | 1                                  |
| 5                 | 2                | 2                                  |
| 6                 | 2                | 3                                  |
| 7                 | 2                | 3                                  |
| 8                 | 2                | 4                                  |
| 9                 | 2                | 4                                  |


### HOLD DOWN BRACKET (OPTIONAL)

Hold down brackets using two small screws, screw hold down bracket to window facing or wall. Snap bracket pin ends into the hole at bottom rail end.




## ATTACHING THE VALANCE

Engage the top leg of the valance clip into the groove on the back of the valance. Then push the valance towards the headrail to engage the bottom leg.



### HOLD DOWN BRACKET (OPTIONAL)

If your blind has been supplied with valance returns slide the valance return clip onto the valance. Slot the other end of the valance clip onto the valance return and align the edge.




## INSTALLING CHILD SAFETY DEVICE

The safety cleat shall be installed as close to the headrail as possible and in all cases not less than 1500mm from the floor. The cord must be fully accumulated around the safety cleat(s) when the blind is not in use. Use the table below to determine the distance required between the cleats to fully accumulate the cords when the blind is fully raised.


| Drop of Blind | *Distance between cord cleats (centre to centre) |
|---------------|--|
| 1-1000mm      | 100mm  |
| 1001-2000mm   | 150mm  |
| 2001-3000mm   | 300mm  |

Place the safety cleat in the desired position on the wall and mark the positions of the holes with a pencil. (Note: Based on cord up to 2.8mm, 17m can be accumulated in total)


(Note: Based on cord up to 2.8mm, 17m can be accumulated in total)



Use the screws provided to attach the safety cleat to the wall.




Wrap the cords around the cord cleats in a figure of 8. When the cords are fully accumulated ensure they are secure so when any cord is pulled no excess cord is released.



## BREAKAWAY CORD CONDENSER

Breakaway cord condenser is pre-fitted to the lift cords so that when a horizontal force is applied to the cords entering the condenser it safely breaks away eliminating any hazardous loops.



**If the cord condenser is pulled apart:**



Untangle and untwist cords.

**For 2 cords:** Press the cord condenser together until it is fully closed.

**For 3 cords:** Place the loose cord in the opening in one half of the cord condenser and press the cord condenser together until it is fully closed.


**For 4 cords:** Place one of the loose cords in the opening in one half of the cord condenser, the remaining loose cord in the opening in the other half and press the cord condenser together until it is fully closed.

If there are any doubts that the cord condenser has not been re-attached correctly it can be tested by placing your arm between the cords and pressing downwards. The condenser should break apart with minimal force, if it does not breakaway tie cords out of reach of children and contact a reputable blind company to repair the blind.



## TILT OPERATION

**To tilt blind:** Pull on required tilt cord tassel to tilt slats to the open/closed position.



Tilt blind horizontal before raising/lowering to extend the life of the blind.

**To lower blind:** Move lift cord towards the middle of the blind pulling down gently until cord lock releases.

**To raise blind:** Pull lift cord downward until blind reaches desired height.

**To lock cords:** Pull lift cord towards the outside of the blind and release. The cord will lock automatically.

### WARNING

Young children can be strangled by loops in pull cords, chains, tapes and inner cords that operate the product.  
To avoid strangulation and entanglement, keep cords out of the reach of young children.

Cords may become wrapped around a child's neck.

Move beds, cots and furniture away from window covering cords.  
Do not tie cords together. Make sure cords do not twist and create a loop.

## MAINTENANCE

The product is maintenance free however we recommend that regular visual checks are completed to ensure that no components have been damaged, which could result in operating difficulties and/or cause a safety risk.  
If any maintenance is required we recommend that the work is carried out immediately, by a reputable blind company.



**make it  
safe**<sup>TM</sup>

